

Concrete - Dry Pour Schedule

2"SLAB

MIST 30-60 seconds
WAIT AN HOUR
MIST 30-60 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds

WATER PROCESS

3"SLAB

MIST 30-60 seconds
WAIT AN HOUR
MIST 30-60 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds

4"SLAB

MIST 30-60 seconds
WAIT AN HOUR
MIST 30-60 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds
WAIT AN HOUR
LIGHT SHOWER 30 seconds

PULL FORMS AFTER 48 HRS FOR BEST RESULTS

Revision #1
Created 11 February 2026 13:20:59 by Steve Ling
Updated 11 February 2026 13:20:59 by Steve Ling